




DRAW PERFECT STRAIGHT LINES TOTALLY FREEHAND!


How to use the 'FREEHAND DESIGNER' clipboard



Place a regular sheet of paper on top of the 'FREEHAND DESIGNER'.
Place your pen or pencil upright at 90° to the page.



Keep your pen or pencil upright to the page, apply a little pressure and draw perfect straight lines.
You can see the grid through the paper, which also enables you to do your drawings to scale if required.



If you want to take notes or draw non straight lines, apply less pressure, so the point of your pen or pencil overrides the grooves in the 'FREEHAND DESIGNER'.

Great for a quick neat professional sketch or survey first time, everytime.

Clipboards available in metric A4 & A3 versions and US Letter size 8½" x 11" & Ledger 11" x 17" versions.