





DRAW PERFECT STRAIGHT LINES TOTALLY FREEHAND!



How to insert the paper into 'FREEHAND DESIGNER' folder



Open the folder and lift the 'Freehand Designer' sheet forward



Slide the cardboard backing of a regular notepad of paper, into the plastic sleeve at the back of the folder.



Remove the cover off the lo tack adhesive strip on the bottom of the 'Freehand Designer' sheet.

Your 'Freehand Designer folder' is now ready to use.

Freehand Designer folders are available in metric A4 & A3 versions and US Letter size 8½" x 11" versions.