








DRAW PERFECT STRAIGHT LINES TOTALLY FREEHAND!




How to use the 'FREEHAND DESIGNER' folder



Place the 'FREEHAND DESIGNER' under the first sheet of paper.
The top of the notepad holds the top of the page in place, at the bottom is a lo tack adhesive strip which holds the bottom of the page in place.



Place your pen or pencil upright at 90° to the page.
Keep your pen or pencil upright to the page, apply a little pressure and draw perfect straight lines.
You can see the grid through the paper, which also enables you to do your drawings to scale if required.



If you want to take notes or draw non straight lines, apply less pressure, so the point of your pen or pencil overrides the grooves in the 'FREEHAND DESIGNER'.

The freehand grooves are 1/2mm apart so it is possible to draw your lines precisely together.

Great for a quick neat professional sketch or survey first time, every time.

Freehand Designer folders are available in metric A4 & A3 versions and a US Letter size 8½" x 11" version.